

**ILLUSTRATED PARTS LIST
LISTA DE PIEZAS
LISTE DES PIECES**



KUBOTA

MODEL
MODELO **WG972-GL-E3BBH-1**
MODELE

**GASOLINE ENGINE
MOTOR GASOLINA
MOTEUR A ESSENCE**



Kubota

97898-78750
FEB.
FEVRIER 2011
FEBR.

000100



A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

**OIL PAN
ENGRASE LA CACEROLA
CARTER D'HUILE**



A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not Interchangeable; ← new for old; → old for new

**CYLINDER HEAD
CILINDRO CULATA
CULASSE**



A.WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

**GEAR CASE
ENGRANAJE CAJA
CARTER DE DISTRIBUTION**



A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not Interchangeable; ← new for old; → old for new


**HEAD COVER
CULATA CUBIERTA
COUVRE-CULASSE**



A:WG972-GL-E3BBH-1

↔ Interchangeable; ≠ not Interchangeable; ← new for old; → old for new

**OIL FILTER
ACEITE FILTRO
FILTRE D'HUILE**




A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

**GSUGE,OIL
VARILLA DE NIVEL
JAUGE D'HUILE ET GUIDE**




A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not Interchangeable; ← new for old; → old for new

**OIL PUMP
ACEITE BOMBA
POMPE D'HUILE**



A:WG972-GL-E3BBH-1


↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

ARBRE A CAMES ET ARBRE DE PIGNON INTERMEDIAIRE



↔ interchangeable; ≠ not interchangeable; ← new for old; → old for new

010200 PISTON AND CRANKSHAFT PISTON Y CIGUENAL PISTON ET VILEBREQUIN




EG511-029-10

A:WG972-GL-E3BBH-1

REF.No. No. DE REF. POS.No.	PART No. No. REF. REFERENCE	PART NAME	DESCRIPCION	DESIGNATION	Q'TY/S.No. CANTIDAD/No. DE SERIE Q'TE/No.S.	I.C. I/C	REMARKS NOTA REMARQUES
010	E6561-2111-0	PISTON	PISTON	PISTON	3		STD
010	E6561-2191-0	PISTON	PISTON	PISTON	3		+0.50mm
020	E6561-2105-0	ASSY PISTON RING	CONJUNTO PISTON ARO	ENS.SEGMENT	3		STD
020	E6561-2109-0	ASSY PISTON RING	CONJUNTO PISTON ARO	ENS.SEGMENT	3		+0.50mm
030	16871-2131-0	PIN,PISTON	PASADOR,PISTON	AXE DE PISTON	3		
040	15261-2133-0	CIR-CLIP, INTERNAL	ANILLO	CIRCLIP	6		
050	16851-2201-7	ASSY ROD,CONNECTING	CONJ.VARILLA,CNCTND	ENS.BIELLE	3		#
050	16887-2201-0	ASSY ROD,CONNECTING	CONJ.VARILLA,CNCTND	ENS.BIELLE	3		#
060	16851-2198-2	BUSH,PISTON PIN	CASQUILLO,PSTN PSDR	BAGUE DE BIELLE	3		
070	16851-2214-0	BOLT,CONNECTING ROD	TORNILLO,CNCTND VRLL	VIS DE BIELLE	6		
080	16851-2232-3	METAL,CRANKPIN M	METAL,MUNEQUILLA M	COUSSINET DE BIELLE	3		STD SET
080	15861-2231-4	METAL,CRANKPIN	METAL,MUNEQUILLA	COUSSINET DE BIELLE	2		#
080	15861-2297-3	METAL,CRANKPIN	METAL,MUNEQUILLA	COUSSINET DE BIELLE	3		-0.20mm SET
080	15861-2298-3	METAL,CRANKPIN	METAL,MUNEQUILLA	COUSSINET DE BIELLE	3		-0.40mm SET
090	16962-2301-2	COMP.CRANKSHAFT	COMPLETO CIGUENAL	VILEBREQUIN COMPLET	1		
100	07715-03207	BALL	BOLA	BILLE	3		
110	15841-2411-0	GEAR,CRANK	ENGRANAJE,GIRAR	PIGNON	1		
120	05712-00515	KEY,FEATHER	LLAVE,PLUMA	CLAVETTE	1		
130	16460-2347-2	METAL,CRANKSHAFT	METAL,CIGUENAL	COUSSINET DE VILEBR.	1		STD
130	16460-2391-2	METAL,CRANKSHAFT	METAL,CIGUENAL	COUSSINET DE VILEBR.	1		-0.20mm
130	16460-2392-2	METAL,CRANKSHAFT	METAL,CIGUENAL	COUSSINET DE VILEBR.	1		-0.40mm
140	---	BLANK	POSTIZO	BLANC	-		
150	---	BLANK	POSTIZO	BLANC	-		
160	15261-2353-3	METAL,SIDE	METAL,LADO	COUSSINET DE LATERAL	2		STD
160	15261-2395-3	METAL,SIDE	METAL,LADO	COUSSINET DE LATERAL	2		+0.20mm
160	15261-2396-3	METAL,SIDE	METAL,LADO	COUSSINET DE LATERAL	2		+0.40mm
170	15261-2354-4	METAL,SIDE	METAL,LADO	COUSSINET DE LATERAL	2		STD
170	15261-2397-4	METAL,SIDE	METAL,LADO	COUSSINET DE LATERAL	2		+0.20mm
170	15261-2398-4	METAL,SIDE	METAL,LADO	COUSSINET DE LATERAL	2		+0.40mm
180	15841-2325-0	COLLAR,CRANKSHAFT	COLLARIN,CIGUENAL	COLLIER VILEBREQUIN	1		

↔ Interchangeable; ↗ not Interchangeable; ← new for old; → old for new

**FLYWHEEL
VOLANTE
VOLANT MOTEUR**



A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

**FUEL CAMSHAFT
COMBUSTIBLE ARBOL DE LEVAS
ARBRE A CAMES DE CARBURANT**



CGSG1 DID 10

A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

This exploded view diagram illustrates the components of a toilet flush valve assembly. The parts are numbered as follows:


- 160, 180, 170: Small circular components, likely O-rings or washers, located at the top left.
- 150: A bracket or arm component.
- 190, 200: A long, thin rod or lever arm.
- 060, 050, 030: Small cylindrical components, likely O-rings or spacers, located in the middle left.
- 090: A small screw or pin.
- 070: A rectangular plate or base component.
- 080: A square flange or base plate.
- 040, 050: A small circular component and a screw, located at the bottom left.
- 120, 130, 140: Screws or bolts used for assembly.
- 100, 170: A rectangular plate or base component, located in the middle.
- 020: A spring component, located at the top right.
- 010: A long rod or lever arm, located on the right side.

Assembly points are indicated by circled 'A' symbols, showing where components are joined. The diagram also includes a partial view of a toilet bowl and tank at the bottom right, showing the installation location of the assembly.

A:WG972-GL-E3BBH-1

↔ Interchangeable; ≠ not Interchangeable; ← new for old; → old for new

**FUEL FILTER
COMBUSTIBLE FILTRO
FILTRE A CARBURANT**




A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

**CARBURETOR
CARBURADOR
CARBURATEUR**



EG801-000-12

A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

020400




12599-025-10

A:WG972-GL-E3BBH-1

18

SPEED CONTROL PLATE
VELOCIDAD CONTROL PLACA
PLAQUE DE VITESSE-CONTROLE




A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

FUEL PUMP (ELECTRICAL)
COMBUSTIBLE BOMBA(ELECTRICO)
POMPE D'ALIMENTATION (ELECTRIQUE)




EG602-032-10

A:WG972-GL-E3BBH-1

[illegible]

↔ interchangeable; ≠ not interchangeable; ← new for old; → old for new

VAPORIZER
VAPORIZADOR
VETENDEUR



EG283-003-20

A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new


026000



No.	IC	REMARKS
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		
29		
30		
31		
32		
33		
34		
35		
36		
37		
38		
39		
40		
41		
42		
43		
44		
45		
46		
47		
48		
49		
50		
51		
52		
53		
54		
55		
56		
57		
58		
59		
60		
61		
62		
63		
64		
65		
66		
67		
68		
69		
70		
71		
72		
73		
74		
75		
76		
77		
78		
79		
80		
81		
82		
83		
84		
85		
86		
87		
88		
89		
90		
91		
92		
93		
94		
95		
96		
97		
98		
99		
100		

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

IGNITION COIL
ENCENDIDO BOBINA
BOBINE D'ALLUMAGE



A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new


**ALTERNATOR AND PULLEY
ALTERNADOR Y POLEA
ALTERNATEUR ET POULIE**



A:WG972-GL-E3BBH-1

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

**040300 ALTERNATOR [COMPONENT PARTS]
ALTERNADOR [COMPONENTE PIEZAS]
ALTERNATEUR [PARTIES COMPOSANTES]**



19008-050-11

A:WG972-GL-E3BBH-1

REF.No. No. DE REF. POS.No.	PART No. No. REF. REFERENCE	PART NAME	DESCRIPCION	DESIGNATION	Q'TY/S.No. CANT. CADN° DE SERIE Q'TE/No.S.	I.C. I/C I.C.	REMARKS NOTA REMARQUES
010	16678-6401-2	ASSY ALTERNATOR	CONJUNTO ALTERNADOR	ALTERNATEUR COMPLET	1		
020	15881-6411-0	PULLEY,DYNAMO	POLEA,DINAMO	POULIE D'ALTERNATEUR	1		
030	15881-9201-0	NUT	TUERCA	ECROU	1		
040	15881-6415-0	COLLAR	COLLAR	COLLIER	1		
050	66436-6404-0	ROTOR	ROTOR	ROTOR	1		
060	15881-6480-0	COVER, BEARING	CUBIERTA, RODAMIENTO	COUVERCLE	1		
070	16652-6477-0	BEARING, BALL	RODAMIENTO	ROULEMENT A BILLES	1		
080	15881-6481-0	WASHER, THRUST	ARANDELA, EMPUJE	RONDELLE DE BUTEE	1		
090	66436-6402-0	ASSY FRAME, DRIVE END	BASTIDOR, ACCNR FN	BATI	1		
100	15881-6471-0	PLATE, RETAINER	PLACA, RETENEDOR	PLAQUE RETENUE	1		
110	15881-9301-0	SCREW, ROUND HEAD	TORNILLO, RDND CLT	VIS A TETE RONDE	4		
120	15881-6426-0	BOLT, THROUGH	TORNILLO, A TRAVES	VIS, PASSANT	2		
130	16652-6478-0	BEARING, BALL	RODAMIENTO	ROULEMENT A BILLES	1		
140	16678-6406-0	FRAME, END	BASTIDOR, FIN	BATI	1		
150	16678-6423-0	COVER, END	CUBIERTA, FIN	PALIER ARRIERE	1		
160	15881-6485-0	ASSY RECTIFIER	CONJ. RECTIFICADOR	REDRESSEUR	1		
170	15881-6490-0	BUSH, INSULATION	CASQUILLO, ASLMNT	BAGUE ISOLANTE	1		
180	16652-6431-0	HOLDER, BRUSH	SOPORTE, ESCOBILLA	PORTE-BALAI	1		
190	15881-6409-0	BRUSH	ESCOBILLA	PATTE D'ATTACHE	2		
200	15881-6433-0	SPRING, BRUSH	RESORTE, ESCOBILLA	RESSORT DE BALAI	2		
210	15881-9302-0	SCREW, ROUND HEAD	TORNILLO, RDND CLT	VIS A TETE RONDE	2		
220	15881-9303-0	SCREW, ROUND HEAD	TORNILLO, RDND CLT	VIS A TETE RONDE	6		
230	15881-9304-0	SCREW, ROUND HEAD	TORNILLO, RDND CLT	VIS A TETE RONDE	1		
240	15881-9104-0	BOLT	TORNILLO	VIS	3		
250	15881-9202-0	NUT	TUERCA	ECROU	2		
260	15881-9105-0	BOLT	TORNILLO	VIS	2		
270	14182-9203-0	NUT	TUERCA	ECROU	1		
280	16652-6460-0	ASSY REGULATOR	CONJUNTO REGULADOR	REGULATEUR	1		

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

**STARTER
MOTOR DE ARRANQUE
DEMARREUR**




A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not Interchangeable; ← new for old; → old for new

040500 STARTER [COMPONENT PARTS]
MOTOR DE ARRANQUE [COMPONENTE PIEZAS]
DEMARREUR [PARTIES COMPOSANTES]



1G958-133-20

A:WG972-GL-E3B8H-1

REF.No. No. REF. POS.No.	PART No. No. REF. REFERENCE	PART NAME	DESCRIPCION	DESIGNATION	Q'TY/S.No. CANTIDAD/S DE SERIE Q'TE/No-S.	I.C. I/C I.C.	REMARKS NOTA REMARQUES
					A		
010	67980-3115-0	ASSY STARTER	CONJ.MOTOR ARRANQUE	ENS.DEMARREUR	1		
020	6A100-3116-0	ASSY YOKE, STARTER	CONJ.YUGO,MTR ARRNQ	ENS.FOURCHE	1		
030	14958-6338-0	ASSY HOLDER	CONJUNTO SOPORTE	ENS.SUPPORT	1		
035	14958-6348-0	SPRING,BRUSH	RESORTE,ESCOBILLA	RESSORT DE BALAI	4		
040	6A100-3117-0	ASSY ARMATURE	CONJUNTO INDUCIDO	ENS.ARMATURE	1		
045	15504-6353-0	BEARING,BALL	RODAMIENTO	ROULEMENT A BILLES	1		
047	15504-6350-0	BEARING,BALL	RODAMIENTO	ROULEMENT A BILLES	1		
050	K3511-8143-0	ASSY CLUTCH, STARTER	CONJ.EMBRAGUE	ENS.EMBRAYAGE	1		
060	67980-3118-0	ASSY HOUSING, STARTER	CONJ.CARcasa	ENS.CARTER DEMARREUR	1		
070	6A100-3119-0	BEARING	RODAMIENTO	ROULEMENT	1		
080	K3511-8145-0	ASSY FRAME	CONJUNTO BASTIDOR	ENS.CHASSIS	1		
090	12182-6329-0	COVER	CUBIERTA	COUVERCLE	1		
100	14958-6353-0	ASSY BEARING	CONJUNTO RODAMIENTO	ENS ROULEMENT	1		
105	14958-6306-0	BEARING	RODAMIENTO	ROULEMENT	1		
110	K3511-8146-0	ASSY SHAFT, STARTER	CONJ.EJE,MTR D ARRNQ	ENS.ARBRE	1		
120	14958-6326-0	GEAR	ENGRANAJE	ENGRENAGE	3		
130	14958-6327-0	GEAR	ENGRANAJE	ENGRENAGE	1		
140	14958-6305-0	LEVER	PALANCA	LEVIER	1		
150	12181-6308-0	ASSY SWITCH,MAGNETIC	CONJ.CONMUTADOR	SOLENOIDE	1		
160	14958-6317-0	RING,SNAP	ARO,BRCH D PRSN	BAGUE ELASTIQUE	1		
170	12181-6322-0	RING,SNAP	ARO,BRCH D PRSN	BAGUE ELASTIQUE	1		
180	13816-6346-0	COLLAR	COLLAR	COLLIER	1		
190	14958-9401-0	WASHER,PLAIN	ARANDELA,SIMPLE	RONDELLE FREIN	1		
200	14958-9402-0	WASHER,PLAIN	ARANDELA,SIMPLE	RONDELLE FREIN	1		
210	14958-9403-0	WASHER,PLAIN	ARANDELA,SIMPLE	RONDELLE FREIN	1		
220	14958-9404-0	PLATE	PLACA	PLAQUE	1		
230	16611-9202-0	NUT	TUERCA,HEXAGONO	ECROU HEXAGONAL	1		
240	14278-9201-0	NUT	TUERCA	ECROU	2		
250	11460-6332-0	BOLT,THROUGH	TORNILLO,A TRAVES	VIS,PASSANT	2		
260	13801-9410-0	WASHER,SPRING	ARANDELA DE MUELLE	RONDELLE GROWER	1		

↔ Interchangeable; ≠ not Interchangeable; ← new for old; → old for new

DEMARREUR [PARTIES COMPOSANTES]




A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not Interchangeable; ← new for old; → old for new

**OIL SWITCH/THERMOMETER
MANOCONTACTO DE ACEITE/TERMOMETRO
CONTACT A HUILE THERMOMETRE**




010

A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not Interchangeable; ← new for old; → old for new

**WATER PIPE
AGUA TUBO
TUYAU D'EAU**




A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

**COOLER FAN
VENTILADOR
VENTILATEUR**



EG261-005-10

A:WG972-GL-E3BBH-1

[illegible]

↔ interchangeable; ≠ not interchangeable; ← new for old; → old for new

**VALVE AND ROCKER ARM
VALVULA Y BALANÇIN BRAZO
SOUPAPES ET CULBUTEURS**



A:WG972-GL-E3BBH-1

↔ interchangeable; ≠ not interchangeable; ← new for old; → old for new

060100




No.	LC	REMARKS
-----	----	---------

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new


060200



No.	IC	REMARKS
-----	----	---------

↔ Interchangeable; ≠ not Interchangeable; ← new for old; → old for new

STARTER SWITCH
MOTOR DE ARRANQUE CONMUTADOR
INTERRUPTEUR DE DEMARREUR




1G646-017-10

A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not Interchangeable; ← new for old; → old for new

**ACCESSORIES AND SERVICE PARTS
ACCESORIOS Y SERVICIO PIEZAS
ACCESSOIRES ET PIECES DE SERVICE**




A:WG972-GL-E3BBH-1


[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

080900 LABEL AND OPERATOR'S MANUAL
ETIQUETA Y DEL OPERADOR MANUAL
ETIQUETTE ET MANUEL DE L'UTILISATEUR

[illegible]

UPPER GASKET KIT[OPTION]
SUPERIOR JUNTA KIT[OPCION]
JEU DE JOINTS SUPER[OPTION]



EG601-015-20

A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

090002



A:WG972-GL-E3BBH-1

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

OPTION
OPCION
OPTION



A:WG972-GL-E3BBH-1

[illegible]

↔ Interchangeable; ~~≠~~ not interchangeable; ← new for old; → old for new