

SPARE PARTS MANUAL

FLEXTOOL DUST COLLECTOR FDC-1A1



Version 1.0 (October 2025)

HOW TO READ THIS SPARE PARTS MANUAL

The following section explains the different symbols and remarks used in this manual and how to interpret the information outlined in the following pages.

Section 1 – Diagram and parts list

- Item No : Used to reference the spare part in the diagram to the parts list.
- Product Code : Used to indicate the unique Flextool spare parts product code used when ordering parts.


Product code can be presented in the following ways:

- Number : Signifies the unique Flextool spare parts product code used when placing orders.
 - Blank : Used for parts pending formal part number assignment at the time of publication. Also denotes that the spare parts are not sold separately or are unavailable from Flextool.
 - See remarks : Indicates that the spare parts are part of an assembly, service kit or is part of a serial number range where a particular part is used. Please refer to remarks to find further information.
- Description : Used to provide a concise description of the spare part such as size, length, diameter, models, etc.
 - Qty : Indicates the quantity of part(s) required for the equipment. Please verify the required quantity when placing an order.
 - Remarks : Refers to additional information, including assembly kit, service kit and serial number range where particular part is used
 - AS : Refers to the parts supplied with an assembly kit.
 - SK : Refers to the parts supplied with a service kit.
 - Serial number : Indicates the range of serial number where particular part is used.

Section 2 – Fast moving spare parts


FLEXTOOL DUST COLLECTOR FDC-1A1

Description	Product Code
FLX DUST COLLECTOR BAGGING SYSTEM 4 PACK	FT100467-UNIT
FLX DUST COLLECTOR FILTER H13	FT100469-UNIT
FLX FILTER FDC-1A1	NPS03352-UNIT
FLX SWITCH	NPS03365-UNIT




Accessories

Item No.	Product Code	Description	Qty	Remarks
1	FT101804-UNIT	FLX DUST COLLECTOR AUTO CLEAN FDC-1A1 (BER-AC18)	1	
2	FT101805-UNIT	FLX D50 ROTATE CONNECTOR (BER-C2032)	1	
3	FT100471-UNIT	FLX DUST COLLECTOR D50 HOSE CUFF (BER-S8006)	1	
4	FT100464-UNIT	FLX DUST COLLECTOR HOSE 50MM (7.5M) (BER-S8008)	1	
5	FT100465-UNIT	FLX DUST COLLECTOR WAND ASSY 50MM (BER-S8046)	1	
6	FT100466-UNIT	FLX DUST COLLECTOR FLOOR NOZZLE 50MM (BER-S8045)	1	




Frame

Item No.	Product Code	Description	Qty	Remarks
1	NPS03344-UNIT	FLX WAGON COMPLETE PACKING (BER-C2139)	1	
2	NPS22295-UNIT	FLX BARREL HOLDER (BER-C2159)	2	
3	NPS22290-UNIT	FLX HEX BOLT M6X12 (BER-S0010)	4	
4	NPS22293-UNIT	FLX NUT M6 (BER-S0011)	1	
5	NPS22271-UNIT	FLX NYLON CABLE TIE STORAGE (BER-C2083)	1	
6	NPS22300-UNIT	FLX HEXAGON BOLT M10X60 (BER-S0032)	2	
7	NPS22301-UNIT	FLX PLAIN CUSHION M10 (BER-S0045)	2	
8	NPS22272-UNIT	FLX LOCK NUT M10 (BER-S0015)	2	
9	NPS22302-UNIT	FLX UNIVERSAL WHEELS 3" (BER-S9030)	2	
10	NPS22303-UNIT	FLX HEAVY DUSTY CASTER 8" (BER-S9011)	2	
11	NPS22304-UNIT	FLX HEXAGON BOLT M12X100 (BER-S0033)	2	




Top Housing

Item No.	Product Code	Description	Qty	Remarks
1	NPS22275-UNIT	FLX TOP HAT (BER-C2205)	1	
2	NPS22276-UNIT	FLX BALL HEAD NUT M6 (BER-S0099)	1	
3	NPS22315-UNIT	FLX HOLDER (BER-S0059)	6	
4	NPS22277-UNIT	FLX HEXAGON SOCKET BOLT M6X35 (BER-S0023)	6	
5	NPS22306-UNIT	FLX DRIVER MODULE -240V (BER-B0042)	1	
6	NPS03345-UNIT	FLX WIND COLLECTOR (BER-C2393)	1	
7	NPS22307-UNIT	FLX REVERSING VALUE ASSEMBLY (BER-B0044)	2	
8	NPS03390-UNIT	FLX SEAL RING 360 (BER-C3029)	1	
9	NPS03346-UNIT	FLX FILTER FIXED PLATE (BER-C2394)	1	
10	NPS03349-UNIT	FLX FILTER BAFFLE (BER-C2395)	1	
11	NPS03350-UNIT	FLX DOCKING CONDUCTOR (BER-S2031)	1	
12	NPS03351-UNIT	FLX EXTERNAL THREAD (BER-C3035)	2	
13	FT101806-UNIT	FLX FILTER FDC-1A1 (BER-S8108)	2	
14	NPS22312-UNIT	FLX HOSE CLAMP 40-63 (BER-S0092)	2	
15	NPS22314-UNIT	FLX 50MM HOSE D50X90MM (BER-S8007)	1	
16	FT100471-UNIT	FLX DUST COLLECTOR D50 HOSE CUFF (BER-S8006)	1	




Barrel

Item No.	Product Code	Description	Qty	Remarks
1	NPS07261-UNIT	FLX BOLT M6X16 (SY-GB/T7991-06-16)	4	
2	NPS22267-UNIT	FLX LOCKNUT M6 (BER-S0013)	4	
3	NPS22315-UNIT	FLX HOLDER (BER-S0059)	2	
4	NPS03354-UNIT	FLX PIN (BER-C2022)	1	
5	NPS03355-UNIT	FLX D50 INLET (BER-C3097)	1	
6	NPS03356-UNIT	FLX INLET (BER-C3016)	1	
7	NPS03357-UNIT	FLX INLET WASHER D50 (BER-C3017)	1	
8	NPS03358-UNIT	FLX SOCKET HEAD SCREW M6X20 (BER-S0022)	2	
9	NPS22267-UNIT	FLX LOCKNUT M6 (BER-S0013)	2	
10	NPS22317-UNIT	FLX FLAP HOLDER (BER-C2092)	1	
11	NPS22338-UNIT	FLX FLAP KIT AY (BER-C2090)	1	
12	NPS22298-UNIT	FLX BAGGING SYSTEM HOLDER (BER-C2084)	1	
13	NPS22268-UNIT	FLX HEXAGON BOLT M6X60 (BER-S0028)	1	
14	NPS22282-UNIT	FLX NUT M8X15 (BER-S0101)	2	
15	NPS22339-UNIT	FLX RUBBER RING (BER-S8036)	1	
16	NPS22318-UNIT	FLX BUNDLING BELT (BER-S0090)	1	
17	FT100467-UNIT	FLX DUST COLLECTOR BAGGING SYSTEM 4 PACK (BER-S8035)	1	
18	NPS03359-UNIT	FLX BARREL (BER-C2396)	1	
19	NPS03360-UNIT	FLX INLET COVER (BER-C2397)	1	



Motor

Item No.	Product Code	Description	Qty	Remarks
1	NPS03361-UNIT	FLX MOTOR COVER TOP (BER-C2398)	1	
2	NPS03363-UNIT	FLX RUBBER EDGE TRIM (BER-S9026)	1	
3	NPS22290-UNIT	FLX BOLT M6X12 (BER-S0010)	12	
4	NPS03364-UNIT	FLX MOTOR (BER-S1073)	1	
5	NPS03365-UNIT	FLX SWITCH (BER-S1070)	1	
6	NPS22319-UNIT	FLX CONNECTOR PG11 (BER-S0006)	1	
7	NPS22320-UNIT	FLX CABLE WITH PLUG (BER-S2002)	1	
8	NPS03367-UNIT	FLX MOTOR COVER FRONT (BER-C2129)	1	
9	NPS22321-UNIT	FLX VACUUM METER (BER-S9022)	1	



Filter

Item No.	Product Code	Description	Qty	Remarks
1	NPS22292-UNIT	FLX NUT M8 (BER-S0091)	2	
2	NPS22324-UNIT	FLX HEPA FILTER TOP COVER (BER-C2333)	1	
3	FT100469-UNIT	FLX DUST COLLECTOR FILTER H13 (BER-S8031)	1	
4	NPS03368-UNIT	FLX HEPA FILTER COVER (BER-C2334)	1	
5	NPS22293-UNIT	FLX NUT M6 (BER-S0011)	6	
6	NPS22326-UNIT	FLX SHOCK ABSORBER RING (BER-C3007)	2	
7	NPS03364-UNIT	FLX SINGLE PHASE MOTOR (BER-S1073)	1	
8	NPS22328-UNIT	FLX SCREWS-1 M6-76.5 (BER-S0086)	3	
9	NPS22329-UNIT	FLX TS MOTOR FIXED PLATE (BER-C2123)	1	
10	NPS22330-UNIT	FLX SCREWS-2 M6-96.5 (BER-S0087)	3	
11	NPS03369-UNIT	FLX CHECK VALVE PLATE (BER-C3054)	1	
12	NPS22333-UNIT	FLX CHECK VALVE (BER-C3055)	1	



Flextool

1956 Dandenong Road, Clayton VIC 3168, Australia

Phone (AUS): 1300 353 986

flextool.com.au

ABN 80 069 961 968

This manual summarises our best knowledge of the product based on the information available at the time of publication. You should read this manual carefully and consider the information in the context of how the product will be used. Our responsibility for products sold is subject to our standard terms and conditions of sale.

DISCLAIMER:

Any advice, recommendation, information, assistance or service provided by us in this manual is given in good faith and is believed by us to be appropriate and reliable. However, any advice, recommendation, information, assistance or service provided by us is provided without liability or responsibility PROVIDED THAT the foregoing shall not exclude, limit, restrict or modify the right entitlements and remedies conferred upon any person or the liabilities imposed upon us by any condition or warranty implied by Commonwealth, State or Territory Act or ordinance void or prohibiting such exclusion limitation or modification. The product can be expected to perform as indicated in this manual so long as operation and operational procedures of the individual products are followed as recommended in this manual.

Design and technical specifications may be subject to changes.

© This publication is copyright. All rights are reserved. Flextool is a registered trade mark of Parchem Construction Supplies Pty Ltd.