

PARTS LIST / パーツリスト

ROBIN ENGINE

EH09-2D

EH09-2F

FOR MIKASA PRODUCTS

三笠製品用

803-07405

FOR MODEL / 適用モデル

MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1732~)	SPEC.NO.H092D45000 (JPN)
MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1717~)	SPEC.NO.H092D45010 (EXP)
MT-52F / MTR-60SF (N1429 ~)	SPEC.NO.H092D45020 (JPN)
MT-52FW	SPEC.NO.H092D45030 (EXP)
MT-52FW	SPEC.NO.H092D45040 (JPN)
EH09-2F (E/G No.F130393~)	
MT-55,55L (U6883~) / MTR-40F	SPEC.NO.H092F45011 (EXP)
MT-55,55L (T8623~) / MTR-40FA	SPEC.NO.H092F45000 (JPN)
MT-55L-SS (U1166~)	// (JPN)

TAMPING RAMMAERR

タンピングランマー

MIKASA SANGYO CO., LTD.

三笠産業株式会社

ご使用の前に


HOW TO USE THIS PARTS CATALOG

ロビンエンジンには、通常、製品仕様識別のため、ラベルがエンジンに貼付されています。このラベルにより、製品番号が確認できます。なお、製品番号(11桁)と管理番号(4桁)が連続表示されており、この15桁を **PROD.No.** と称し、次のような構成となっています。

In order to identify product specification, a label is generally stuck on each ROBIN engine.

The **SPEC.No.** can be confirmed by the label.

The label indicates a 15-digit alphabetic-numeric string of **PROD.No.** which consists of the **SPEC.No.** (11-digit) and the **CODE No.** (4-digit) as illustrated below.



—ラベル表示例—MARKING EXAMPLE



PROD.No. (15桁) のラベルは、ブロワハウジング、フューエルタンク、シリンダバッフル、ヘッドカバーのいずれかの見易い位置に貼付してあります。また、シリンダバッフルに打刻の場合もあります。

The 15-digit PROD.No. label is stuck on the part where it is easily found such as on blower housing, on fuel tank, on cylinder baffle, or on head cover. In some cases, it is stamped on the cylinder baffle.

注意

NOTE

このパーツカタログの記載内容は、予告なく変更することがありますので、あらかじめご承知おき下さい。

Please note that this part catalog is subjected to change without notice.

PARTS REMARK INDEX

How to read the marks and remarks used in this parts book.

Section 1 : Explanation of Code Use In “MRK” Column

OO : Interchangeable between the new part and the old one.

XX : Not Interchangeable between new and old.

OX : New part is usable for the old machine but the old part is not usable for the new machine.

XO : The old part is usable for the new machine but the new part is not usable for the old machine.

Note : In case of the lack of interchangeability between the new part and old part, a new part may be used by replacing all other parts found in the assembly. In this case, refer to section 2 for instruction on identifying other parts involved in a new assembly.

AD : Newly established(added)

DC : Suspended(discontinued)

NC : Part number changed

QC : Quantity used has been changed

NS : Not supplied individually but supplied in an assembly or a group.

AS : Special part designed to allow interchangeability between new and old part.

CR : Correction

Section 2 : Items Found In “Remark” Column

Serial Numbers - Where indicated, this indicates a serial number range (inclusive) where a particular part is used.

Model Number - Where indicated, this shows that the corresponding part is utilized only with this specific model number or model number variant.

or * : All parts with the same number following # or * belong to the same assembly. this part cannot be interchanged individually with any other assemblies to replace an old part (indicated by #), with a new part(indicated by *), then all other parts of that assembly must be replaced with new ones.

Note : If more than one of the same reference number is listed, the last one listed indicates newest(or latest)part available.

Section 3: Example

REF NO.	PART NO.	PART NAME	QTY	MRK	REMARKS
457(1)	5122-09230	Hinge Metal, Upper/24g	1		-1070 #3 (5)
457(2)	5072-09420	Hinge Metal, Upper M16	1	OX(3)	U1071-(6) * 3(7)

(1) Old part

(2) New part

(3) New part usable with old machine, but old part not usable with new machine (reference section 1).

(4) Old part number is used through this machine serial number.

(5) Old part, used in an assembly with other parts marked with #3. To use this part on a new machine, all other parts in this assembly must be replaced with old ones.

(6) New part put into use starting with this serial number and is still current.

(7) New part used in an assembly with other parts marked * 3, to use this part as a replacement for an old part, all other * 3 marked parts must be changed at the same time.

Section 4: Items Found In “MK2” Column

(only for suspended products)

! OO (“OO” is shown in figure) : The part shown in lower line is supplied.

! SD : Not available due to termination of production.

! NS : Not supplied individually, but supplied in an assembly or a group.

! PD : Supplied as unit product.

SS : Not available after stock run out.

(The contents of this parts catalog are subject to change without notice.)

部品変更マークの見方

1. パーツリスト中で使用されている項目および記号の意味は下記の通りです。

MRK欄の記号の意味

- OO : 新、旧部品は相互に互換性あり
- XX : 新、旧部品は相互に互換性無し
- OX : 新部品は、旧部品の代わりに使用できます。その逆は使用できません。
- XO : 旧部品は、新部品の代わりに使用できます。その逆は使用できません。
- AD : 新規追加使用となった部品
- DC : 使用を中止した部品
- NC : 部品コードナンバーの変更
- QC : 使用個数の変更
- NS : 単品での販売をしない部品
- AS : 部品変更に伴い新旧部品の互換性を持たせるための特殊部品
- CR : 誤記訂正 (正規部品)

注記1 : 個々の新、旧部品で互換性が無い場合でも、複数の部品を同時に交換する事により、新部品を旧部品の代わりに使用できる場合が有ります。この場合、下記のREMARKS (備考) 欄に記号*O, #Oが記入されています。

MK2欄の記号の意味

- !OO (OO内は数字) : 供給する補用部品の互換部品番号 (MK2欄に!のある部品は供給出来ません)
- !SD (SD) : 生産終了等のため供給出来ない部品
- !NS (NS) : 単品での販売を行わない部品 (アッシでの販売)
- !PD (PD) : 製品価格表に価格が表記されており、部品での販売をしない部品 (製品で販売)
- SS : 生産終了等のため在庫の販売終了後は供給出来ない部品

REMARKS (備考) 欄の記号の意味

- *O, #O : 互換性のある部品グループを示します。 例) *1 : 新部品のグループ
#1 : *1に対応する旧部品のグループ
- OOOO : スペックNo. または製造番号OOOO号機まで使用
- OOOO- : スペックNo. または製造番号OOOO号機から使用
例) -1001 : 1001号機まで使用
1002- : 1002号機から使用

注記2 : 互換性の無い設計変更を行った場合、参考としてREMARKS (備考) 欄に適用号機またはスペックNo. を明記して有りますので、部品発注時にご参照ください。

注記3 : 部品表作成の都合上、MK2欄が省略される場合、各記号が指定欄以外に記入される場合および記号が重複する場合があります。

2. 使用例

Ref No.	PART No.	部品名称	Q'TY	MRK	REMARKS
1	1111-11111	リンク	1		
1	1111-22222	リンク	1	OO	
2	2222-22222	レバー	1		#1 -1150
2	2222-33333	レバー	1	XX	*1 1151-
3	3333-33333	コネクター	1	AD	*1 1151-

(注意 : 同一 Ref No. で示す部品は新旧両部品がある事を示します。この場合、旧部品の下に新部品を記し、旧部品との互換性を新部品のMRK欄に示します。)

- 1 OO 【OO】 部品番号 1111-11111 の旧リンクは、部品番号 1111-22222 の新リンク
に変更されたもので、新旧部品の相互に互換性があります。
- 2 #1 -1150 【XX】 部品番号 2222-22222 の旧レバーは、部品番号 2222-33333 の新レバー
と交換出来ません。
- 2 XX *1 1151- 【AD】 部品番号 3333-33333 の新コネクターは新規追加になった部品です。
【#1、*1】 旧部品のグループ (#1のマークで示した部品) は、新部品の
グループ (*1のマークで示した部品) と全ての部品を交換すること
により互換性があります。
- 3 AD *1 1151- 【-1150、1151-】 部品番号 2222-22222 の旧レバーは、製造番号 1150 号機まで
使用されています。また、部品番号 2222-33333 の新レバーと部品番号
3333-33333 の新コネクターは製造番号 1151 号機から使用されています。


EH09-2D ランマー (Rammer type) EH09-2F

AO00

1.CRANK CASE / クランクケース

FIG.100

for MIKASA



EH092

284010001

- | | | |
|-----------------------------|---------------------|--------------------------|
| MT-55 (N1800~N5484)(P5485~) | / MTR-40F (N1732~) | SPEC.NO.H092D45000 (JPN) |
| MT-55 (N1800~N5484)(P5485~) | / MTR-40F (N1717~) | SPEC.NO.H092D45010 (EXP) |
| MT-52F | / MTR-60SF (N1429~) | SPEC.NO.H092D45020 (JPN) |
| MT-52FW | | SPEC.NO.H092D45030 (EXP) |
| MT-52FW | | SPEC.NO.H092D45040 (JPN) |
| EH09-2F (E/G No.F130393~) | | |
| MT-55,55L (U6883~) | / MTR-40F | SPEC.NO.H092F45011 (EXP) |
| MT-55,55L (T8623~) | / MTR-40FA | SPEC.NO.H092F45000 (JPN) |
| MT-55L-SS (U1166~) | | // (JPN) |

1. CRANK CASE / クランクケース

** A00 **


REF NO.	PART NO.	PART NAME	部 品 名 称	Q' TY	MRK	MK2	REMARKS
10	20F-10104-21	CRANK CASE CP/EH09-2/MT	クランクケースCP/EH09-2/MT	1			
20	237-14202-03	VALVE GUIDE O/S	バルブガイド O/S	2			
26	277-16010-01	STEM SEAL	ステムシール /EX13	1			
30	044-02000-70	OIL SEAL TB20326	オイル シール TB20326 EY08	1			
40	060-02001-10	BALL BEARING 6004C3	ボールベアリング 6004C3	1			
50	031-00600-20	DOWEL PIN	ダウエルピン !JH	2			
70	010-50604-30	STUD	スタッド	2			
75	044-00600-20	OIL SEAL/EX17	オイルシール/EX17	1			
80	040-11400-30	PLUG	プラグ	1			
90	021-11400-20	GASKET	ガスケット	1			
150	274-16001-13	STIFFENER	スティフナー	1			
160	001-14082-50	BOLT & WASHER	ボルト&ワッシャー	4			
161	001-14083-00	BOLT & WASHER AY	ボルト&ワッシャー AY	2			
205	024-10900-60	GROMMET	グロメット EH09-2D/MT	1			
210	20F-11101-31	MAINBEARING COVER CP	メインベアリングカバー/EH09-2MT	1			
220	044-02001-10	OIL SEAL 20X32X6	オイルシール 20x32x6	1			
230	060-02001-10	BALL BEARING 6004C3	ボールベアリング 6004C3	1			
250	284-45003-01	GOVERNOR GEAR CP	ガバナギヤ CP/EH09-2D	1			
260	205-41901-03	GOVERNOR SLEEVE	ガバナスリーブ /EY, EH,	1			
265	001-39085-00	STUD	スタッド	4			
268	031-00600-20	DOWEL PIN	ダウエルピン !JH	2			
270	230-63601-11	OIL GAUGE/EY08	オイルゲージ P付/EY08, MVC40	1			
280	X21-31600-20	GASKET	ガスケット	1			
300	013-00602-00	BOLT & WASHER AY	ボルト&ワッシャー AY	9			
430	274-15001-23	ADAPTER, FLANGE	アダプター、フランジ /EH09	1			
437	002-18080-00	NUT	ナット	4			
438	003-20080-00	SPRING WASHER	スプリングワッシャー M8	4			
439	003-11080-00	WASHER	ワッシャー /EH12-2, MT	4			
610	284-13001-10	CYLINDER HEAD AY	シリンダヘッド AY/EH09-2D	1			
620	284-15001-13	GASKET (HEAD)	ガスケット、ヘッド /EH09-2D	1			
630	011-00802-10	FLANGE BOLT	フランジボルト	2			
631	010-00804-10	BOLT	ボルト	2			
680	284-15502-03	ROCKER COVER/EH09-2/MT	ロッカーカバー/EH09-2/MT	1			
685	284-14502-03	OIL SHELTER PLATE (2)	オイルシェルタープレート(2)/09-2	1			
690	284-16007-03	GASKET (ROCKER COVER)	ガスケット、RカバーEH09-2/MVC	3			
700	277-15011-03	PIPE KNOCK	パイプノック /EX13	2			
710	011-00604-00	FLANGE BOLT	フランジ ボルト EH09-2D/MT	4			
721	284-15602-03	BREATHER PLATE/EH09-2	ブリーザプレート/EH09-2/MT	1			
722	284-16001-03	LEAF VALVE/EH09-2	リーフバルブ /EH09-2/MT	1			
723	284-16002-03	RETAINER PLATE/EH09-2	リテーナプレート/EH09-2/MT	1			
724	284-14501-03	OIL SHELTER PLATE (1)	オイルシェルタープレート(1)/EH09-2	1			
725	013-10500-20	SCREW AND WASHER AY	スクリュー&ワッシャー AY, RG0120	2			
726	013-10500-20	SCREW AND WASHER AY	スクリュー&ワッシャー AY, RG0120	1			
810	284-17001-03	COVER (CASE) /EH09-2/MT	カバー、ケース/EH09-2/MT	1			
830	230-16006-13	GASKET TAPPET COVER, NA	ガスケット、タペットカバー NA/EY08	1			
860	001-14061-60	BOLT AND WASHER ASS' Y	ボルト&ワッシャーASS' Y	2			
960	284-99004-07	GASKET SET	ガスケットセット/EH09-2/MT	1			

EH09-2F

2.CRANK SHAFT, PISTON / クランクシャフト、ピストン

FIG.200

for MIKASA



EH092

2840200001

MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1732~)	SPEC.NO.H092D45000 (JPN)
MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1717~)	SPEC.NO.H092D45010 (EXP)
MT-52F / MTR-60SF (N1429 ~)	SPEC.NO.H092D45020 (JPN)
MT-52FW	SPEC.NO.H092D45030 (EXP)
MT-52FW	SPEC.NO.H092D45040 (JPN)
EH09-2F (E/G No.F130393~)	
MT-55,55L (U6883~) / MTR-40F	SPEC.NO.H092F45011 (EXP)
MT-55,55L (T8623~) / MTR-40FA	SPEC.NO.H092F45000 (JPN)
MT-55L-SS (U1166~)	// (JPN)


EH09-2D ランマー (Rammer type)
EH09-2F

AOQ0

3.INTAKE , EXHAUST / インテーク, エクゾースト

FIG.300

for MIKASA



EH092

284030001

MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1732~) SPEC.NO.H092D45000 (JPN)
 MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1717~) SPEC.NO.H092D45010 (EXP)
 MT-52F / MTR-60SF (N1429 ~) SPEC.NO.H092D45020 (JPN)
 MT-52FW SPEC.NO.H092D45030 (EXP)
 MT-52FW SPEC.NO.H092D45040 (JPN)

EH09-2F (E/G No.F130393~)

MT-55,55L (U6883~)/ MTR-40F SPEC.NO.H092F45011 (EXP)
 MT-55,55L (T8623~)/ MTR-40FA SPEC.NO.H092F45000 (JPN)
 MT-55L-SS (U1166~) // (JPN)

EH09-2D ランマー (Rammer type)

4-1.CARBURETOR / キャブレター

AOV0

FIG.600

MT-52F/52FW
MTR-60SF

MT-55
MTR-40F


MT-55SGK

for MIKASA

A

B

C



MT-55 (N1800~N5484)(P5485~)	/ MTR-40F (N1732~)	SPEC.NO.H092D45000 (JPN)
MT-55 (N1800~N5484)(P5485~)	/ MTR-40F (N1717~)	SPEC.NO.H092D45010 (EXP)
MT-52F	/ MTR-60SF (N1429~)	SPEC.NO.H092D45020 (JPN)
MT-52FW		SPEC.NO.H092D45030 (EXP)
MT-52FW		SPEC.NO.H092D45040 (JPN)

EH09-2F ランマー (Rammer type)

BKM0


4-2.CARBURETOR / キャブレター

(EH09-2F E/G No, F130393~
 MT-55 製品号機 T-8623~)

FIG.

for MIKASA

210 NO.284-62372-00
 CARBURETOR (09372H)



EH09-2F ※(パーツカタログの内容は予告なく変更する事があります。)

EH09-2F (E/G No.F130393~)

MT-55,55L (U6883~) / MTR-40F (~)

MT-55,55L (T8623~) / MTR-40FA (~)

MT-55L-SS (U1166~)

SPEC.NO.H092F45011 (EXP)

SPEC.NO.H092F45000 (JPN)

// (JPN)

EH09-2D ランマー (Rammer type)
EH09-2F


AOR0

5. AIR CLEANER / エアークリーナー



FIG.310

for MIKASA


MT-52F / MTR-60SF



MT-52FW



MT-55 / MTR-40F



- | | | |
|-----------------------------|---------------------|--------------------------|
| MT-55 (N1800~N5484)(P5485~) | / MTR-40F (N1732~) | SPEC.NO.H092D45000 (JPN) |
| MT-55 (N1800~N5484)(P5485~) | / MTR-40F (N1717~) | SPEC.NO.H092D45010 (EXP) |
| MT-52F | / MTR-60SF (N1429~) | SPEC.NO.H092D45020 (JPN) |
| MT-52FW | | SPEC.NO.H092D45030 (EXP) |
| MT-52FW | | SPEC.NO.H092D45040 (JPN) |
| EH09-2F (E/G No.F130393~) | | |
| MT-55,55L (U6883~) | / MTR-40F | SPEC.NO.H092F45011 (EXP) |
| MT-55,55L (T8623~) | / MTR-40FA | SPEC.NO.H092F45000 (JPN) |
| MT-55L-SS (U1166~) | | // (JPN) |


EH09-2D ランマー (Rammer type)
EH09-2F

AOS0

6.GOVERNOR , OPERATION / ガバナ, オペレーション

FIG.400

for MIKASA



EH092

284040001

- | | | |
|-----------------------------|----------------------|--------------------------|
| MT-55 (N1800~N5484)(P5485~) | / MTR-40F (N1732~) | SPEC.NO.H092D45000 (JPN) |
| MT-55 (N1800~N5484)(P5485~) | / MTR-40F (N1717~) | SPEC.NO.H092D45010 (EXP) |
| MT-52F | / MTR-60SF (N1429 ~) | SPEC.NO.H092D45020 (JPN) |
| MT-52FW | | SPEC.NO.H092D45030 (EXP) |
| MT-52FW | | SPEC.NO.H092D45040 (JPN) |

EH09-2F (E/G No.F130393~)

- | | | |
|---------------------|----------|--------------------------|
| MT-55,55L (U6883~)/ | MTR-40F | SPEC.NO.H092F45011 (EXP) |
| MT-55,55L (T8623~)/ | MTR-40FA | SPEC.NO.H092F45000 (JPN) |
| MT-55L-SS (U1166~) | | // (JPN) |

EH09-2D ランマー (Rammer type)
EH09-2F

AOT0

7.BLOWER HOUSING / ブロアーハウジング

FIG.500

for MIKASA

MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1732~) SPEC.NO.H092D45000 (JPN)
 MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1717~) SPEC.NO.H092D45010 (EXP)
 MT-52F / MTR-60SF (N1429 ~) SPEC.NO.H092D45020 (JPN)
 MT-52FW SPEC.NO.H092D45030 (EXP)
 MT-52FW SPEC.NO.H092D45040 (JPN)

EH09-2F (E/G No.F130393~)
 MT-55,55L (U6883~) / MTR-40F SPEC.NO.H092F45011 (EXP)
 MT-55,55L (T8623~) / MTR-40FA SPEC.NO.H092F45000 (JPN)
 MT-55L-SS (U1166~) // (JPN)

EH092

2840500001

2010/5/17

7. BLOWER HUSING / ブロワハウジング

**** AOT ****

REF NO.	PART NO.	PART NAME	部品名称	Q' TY	MRK	MK2	REMARKS
10	284-51102-13	BLOWER HOUSING/EH09-2/MT	ブロワハウジングEH09-2 MT/銀色	1			
20	284-95102-03	LABEL (MODEL)	ラベル、モデル / EH09-2	1			
40	001-04083-50	FLANGE BOLT	フランジボルト EC35PL	2			
41	001-04082-00	FLANGE BOLT	フランジボルト EH092D/MT	2			
60	284-52601-23	CYLINDER BAFFLE	シリンダバッフル/ EH09-2D	1			
80	011-00600-10	FLANGE BOLT	フランジボルト	1			
110	284-54101-03	COOLING BLOWER/EH09-2	クーリングブロワ/ EH09-2D	1			


EH09-2D ランマー (Rammer type) EH09-2F

AOU0

8.RECOIL STARTER / リコイルスターター

FIG.520

for MIKASA



MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1732~) SPEC.NO.H092D45000 (JPN)
 MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1717~) SPEC.NO.H092D45010 (EXP)
 MT-52F / MTR-60SF (N1429~) SPEC.NO.H092D45020 (JPN)
 MT-52FW SPEC.NO.H092D45030 (EXP)
 MT-52FW SPEC.NO.H092D45040 (JPN)
 EH09-2F (E/G No.F130393~)
 MT-55,55L (U6883~) / MTR-40F SPEC.NO.H092F45011 (EXP)
 MT-55,55L (T8623~) / MTR-40FA SPEC.NO.H092F45000 (JPN)
 MT-55L-SS (U1166~) // (JPN)

EH092

2840500001

2010/5/17

8. RECOIL STARTER / リコイルスターター

** AOU **

REF NO.	PART NO.	PART NAME	部品名称	Q'TY	MRK	MK2	REMARKS
A	284-50211-30	RECOIL STARTER AY	リコイルスターター AY / EH 09- 2	1			
1	274-50115-08	SPIRAL SPRING	スパイラルスプリング / EH 09	1			
2	274-50120-18	REEL	リール	1			
3	274-50112-08	STARTER ROPE	ロープ / EH 09 / Φ 3X1420	1			
4	261-50100-18	STARTER KNOB	スターターノブ / EH 12- 2D	1			
5	270-50125-08	RATCHET	ラチェット / EH 12- 2D	2			
6	274-50131-08	FRICTION SPRING	フリクション スプリング	1			
7	227-50135-08	RETURN SPRING	リターン スプリング / 爪づら用、EY 20	2			
8	270-50261-08	RATCHET GUIDE	ラチェットガイド / EH 12- 2D	1			
11	284-50145-08	STARTER PULLEY/EH09-2	スタータープーリー / EH 09- 2D	1			
24	274-50152-08	SLIDE PLATE B	スライドプレート B	1			
25	131-50150-08	SLIDE PLATE	スライドプレート	1			
49	227-50152-08	SET SCREW	セット スクリュー / EY 20、40、EH	1			
216	9201-00240	DECAL, (M-MARK)	銘板 M-マーク / NP- 24	1			MIKASA
220	011-00600-10	FLANGE BOLT	フランジボルト	3			
230	011-00600-20	FLANGE BOLT	フランジボルト	4			

EH09-2D ランマー (Rammer type) EH09-2F

AOW0

9.ELECTRIC DEVICE / エレクトリックデバイス

FIG.700

for MIKASA

MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1732~)	SPEC.NO.H092D45000 (JPN)
MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1717~)	SPEC.NO.H092D45010 (EXP)
MT-52F / MTR-60SF (N1429 ~)	SPEC.NO.H092D45020 (JPN)
MT-52FW	SPEC.NO.H092D45030 (EXP)
MT-52FW	SPEC.NO.H092D45040 (JPN)
EH09-2F (E/G No.F130393~)	
MT-55,55L (U6883~)/ MTR-40F	SPEC.NO.H092F45011 (EXP)
MT-55,55L (T8623~)/ MTR-40FA	SPEC.NO.H092F45000 (JPN)
MT-55L-SS (U1166~)	// (JPN)

EH092

284070001

2010/5/17

9. ELECTRIC DEVICE / エレクトリック デバイス

** AOW **

REF NO.	PART NO.	PART NAME	部品名称	Q' TY	MRK	MK2	REMARKS
10	284-79330-21	FLY WHEEL CP/EH09-2/MT	フライホイールCP/ EH09-2/MT	1			
11	284-79430-21	IGNITION COIL CP/EH09-2	イグニッションコイルCP/ EH09-2D	1			INCL. 110
30	001-17062-50	BOLT AND WASHER ASS' Y	ボルト&ワッシャー ASS' Y	2			
60	066-00004-71	SWITCH AY/60MM	スイッチAY/60MM/ EY, EH, EX	1			
70	004-35041-20	SCREW AND WASHER ASS' Y	スクリュー&ワッシャー ASS' Y	2			
75	056-60300-10	CLAMP	クランプ	1			
100	065-01403-80	SPARK PLUG	スパークプラグ, BMR4A/NGK	1			
110	284-75102-03	SPARK PLUG CAP/EH09-2	スパークプラグキャップ/ EH09-2D	1			




EH09-2D ランマー (Rammer type)
EH09-2F

AOX0

10.ACCESSORIES / アクセサリーズ

FIG.900

for MIKASA



- MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1732~) SPEC.NO.H092D45000 (JPN)
- MT-55 (N1800~N5484)(P5485~) / MTR-40F (N1717~) SPEC.NO.H092D45010 (EXP)
- MT-52F / MTR-60SF (N1429 ~) SPEC.NO.H092D45020 (JPN)
- MT-52FW SPEC.NO.H092D45030 (EXP)
- MT-52FW SPEC.NO.H092D45040 (JPN)
- EH09-2F (E/G No.F130393~)
- MT-55,55L (U6883~) / MTR-40F SPEC.NO.H092F45011 (EXP)
- MT-55,55L (T8623~) / MTR-40FA SPEC.NO.H092F45000 (JPN)
- MT-55L-SS (U1166~) // (JPN)

EH092

284090001

2010/5/26

10. ACCESSORIES, NEME PLATES / アクセサリーズ, 銘板 ** AOX **

REF NO.	PART NO.	PART NAME	部品名称	Q'TY	MRK	MK2	REMARKS
10	226-90307-10	ACCESSORY TOOL KIT	アクセサリツールキット	1			
162	073-20045-20	LABEL, OIL CAUTION	ラベル オイル コーション	1			
163	073-20044-30	LABEL (CHOKE)	ラベル チョーク / EH09 EC12	1			
166	073-20057-60	LABEL (WARNING) / EXP	ラベル WARNING 絵文字 / EXP	1			EU/EXP
166	9201-08660	DECAL, CAUTION (RAMMER)	銘板、組合せ注意銘板 ランマー用)	1			JAPAN



MIKASA SANGYO CO., LTD.

HEAD OFFICE

No.4-3, Sarugakucho 1-chome,
Chiyoda-ku, Tokyo, 101-0064,
Japan



三笠産業株式会社

本 社 〒101-0064 東京都千代田区猿樂町1丁目4番3号
電話 03-3292-1411 FAX 03-3233-0530
大 阪 支 店 〒550-0012 大阪市西区立売堀3丁目3番10号
電話 06-6541-9631 FAX 06-6541-9660
札 幌 営 業 所 〒003-0030 札幌市白石区流通センター6丁目1番48号
電話 011-892-6920 FAX 011-892-6344
仙 台 営 業 所 〒984-0015 仙台市若林区卸町5丁目1番16号
電話 022-238-1521 FAX 022-238-0331
北 関 東 営 業 所 〒374-0042 館林市近藤町178番地
電話 0276-74-6452 FAX 03-3233-0530
中 部 営 業 所 〒453-0014 名古屋市東区則武1丁目9番4号
電話 052-451-7191 FAX 052-451-0315
中 国 営 業 所 〒731-0138 広島市安佐南区祇園3丁目45番11号
電話 082-875-8561 FAX 082-875-8560
九 州 営 業 所 〒812-0016 福岡市博多区博多駅南5丁目22番5号
電話 092-431-5523 FAX 092-431-5707

《出張所》

・新潟 ・長野 ・金沢 ・四国 ・南九州 ・沖縄

《部品サービスセンター》

〒344-0053 春日部市緑町3丁目4番39号
部 品 課 電話 048-734-2401 FAX 048-736-6787
サ ー ビ ス 課 電話 048-734-2402 FAX 048-734-7678

・館林物流センター ・技術研究所 ・館林工場 ・春日部工場