

FLEXTOOL DRIVE UNIT FDU-D2 (DIESEL)

Engineered with durability and efficiency at the forefront, Flextool Drive Units are designed for use in the construction, hire, mining and manufacturing industries. They are fitted with a quick action coupling for easy connection to a wide range of flexible shaft submersible pumps and concrete vibrators. Features include a heavy-duty engine protection frame, 3-tooth drive coupling and built-in lifting hook. They are available with petrol or diesel engine to suit any specific job site requirement.

Lifting hook

Central lifting hook for easy and safe onsite handling

Universal bell housing

- Fitted with 3-tooth drive coupling
- Compatible with most flexible shaft submersible pumps and concrete vibrators



Heavy-duty engine protection frame

Powder coated tubular steel roll frame for increased durability

Yanmar L48 engine

- Provides hassle free and long term reliable operation
- With recoil starter

Heavy-duty rubber mounts

For vibration isolation allowing sturdy operation when stationary



PRODUCT & PERFORMANCE SPECIFICATIONS



FLEXTOOL DRIVE UNITS











FDU-P1 (Standard)

FDU-P2 (Super)

FDU-P3 (Heavy-duty)

FDU-D2 (Diesel)

FDU-DE2 (Diesel electric start)

Model	Operating Weight (kg)	Engine Speed (rpm)	Vibration Isolating Mounts	Lifting Hook	Engine Make	Engine Model	Max Rated Power (hp)	Fuel Type	Product Code
FDU-P1 (Standard)	28.5	3000	No	Yes	Honda	GX160	5.5	ð	FT201802-UNIT
FDU-P2 (Super)	32	3000	Yes	Yes	Honda	GX160	5.5	ð	FT201798-UNIT
FDU-P3 (Heavy-duty)	38.5	3000	Yes	Yes	Honda	GX270	9	ð	FT201799-UNIT
FDU-D2 (Diesel)	38	3000	Yes	Yes	Yanmar	L48	4.8	Ō	FT201800-UNIT
FDU-DE2 (Diesel electric start)	52	3000	Yes	Yes	Yanmar	L48	4.8	Ō	FT201819-UNIT



THE FLEXTOOL PROMISE

If the unexpected happens and something goes wrong with your Flextool equipment within the first 12 months of purchase, we'll arrange to give you a loan machine for 2 days, free of charge, while we work to repair or replace your Flextool product.*

flextool.com.au/flextool-promise

*Qualification criteria apply. Terms and conditions for the Flextool Promise can be found at flextool.com.au.

This Technical Data Sheet (TDS) summarises our best knowledge of the product, based on the information available at the time. You should read this TDS carefully and consider the information i the context of how the product will be used. Our responsibility for products sold is subject to our standard terms and conditions of sale. Parchem does not accept any liability either directly or indirectly for any losses suffered in connection with the use of the product whether or not in accordance with any advice, specification, recommendation or information given by it.